

Reusable Sanitary Fitting



1. Use appropriate hose cutting saw to make square cut necessary for proper union with coupling.
CAUTION: OTHER THAN SQUARE CUT WILL PERMIT FAULTY ALIGNMENT WITH POSSIBILITY OF REDUCED USE OR FAILURE.
2. Slide **Nut** onto hose with threads facing out.
3. Slide **Crimp Sleeve** onto hose to a point just short of crimp sleeve end.
4. Position **Fitting** into hose end.
5. Complete insertion of **Fitting** into hose with barb being at maximum depth and **Crimp Sleeve** seated into groove on back of fitting.
6. Thread **Nut** onto **Fitting** and tighten so no threads are exposed.

NOTE: USE OF RECOMMENDED WRENCHES WILL ASSIST IN PROPER COMPLETION OF ASSEMBLY.



Caution: Consult factory if using hose other than the hose for which fitting was designed.
Improper assembly is not warranted.